



## MAINTANANCE

Our Relaxers/recliners have a mechanism with many joints, springs and moving parts. As a result, it is natural that sounds/squeaks from the chassis occur. There is no fault with the chair of that reason. If creaking/-clicking noise occurs from the fitting you must tighten the screws (Picture. 1 and 2) and smear all the joints with a drop of oil. Use penetrating oil that not flows, such as penetrating oil spray. To prevent sounds from the ball bearing spray the bullets inside the bearing with: CRC white lithium grease, or similar.



PICTURE 1



PICTURE 2

Bolts, screws and knobs can loosen after an extended period. This can create damage to the frame and instability to the furniture. Therefore, it is important to check and tighten all bolts, screws and knobs periodically. IMG recommends you to do this at least every four (4) months or as needed.

## SAFETY RULES




**PS!** Please be aware that irregular use might cause risk and squeeze danger!

- The back cover skirt must always be properly fastened with Velcro tape to avoid somebody's hands/fingers getting into the chairs mechanism from the chair's backside.
- Do not allow children to sit and play on or near the chair or to operate the mechanism. The footrest might fold out and the child could get injured.
- Keep hands and feet away from the mechanism. Only the chairs user should operate the mechanism.
- Always leave the chair in upright position with folded in footrest.
- Do not sit on the armrest.
- Never sit on the footrest. Do not use the chair or footrest as step ladder.
- Never lift/carry the chair by the back or the footrest. Lift the chair by grabbing under the chairs arms, base or backside.
- The chair can only be used by one person at a time.
- Armrest protection cover is recommended to use (for fabric cover).
- If parts are missing, broken, damaged or worn – stop use of the product until repairs are made, using factory authorized parts only.

**Failure to follow these warnings could result in serious injury.**

## CONGRATULATIONS

You are now the proud owner of Relaxer by IMG. We are confident you will feel the same as you enjoy the comfort and style of your new furniture.



### IMPORTANT

Read this and other relevant instructions before using the product. Keep this manual for future reference.


## RELAXER, ASSEMBLY INSTRUCTIONS

**PLEASE READ THIS INFORMATION CAREFULLY BEFORE YOU ASSEMBLE AND USE THE CHAIR.**

IMG Relaxers are delivered with separated back and seat. The back is ready for assembly. Please proceed with the following steps:


### STEP 1

Take the center arm and attach the 4 flanges (2 on each side) as shown in the line drawing. It is two type of flange and the one in the front will be marked FRONT on the flange.




### STEP 2

Remove the connection protectors on the back and the flanges/brackets protectors on the seat.




### STEP 3

Attach the back by sliding the connectors into the flanges/brackets on the back part of the seat. Press the back down until you hear "click". Please ensure that you don't tear the skirt cover or that the skirt cover gets squeezed between the back and the seat.



### STEP 4


Use the Velcro tape to fasten the skirt cover onto the lower part of the chair (the cover goes from the back to the back rail frame).



## RELAXER, USER INSTRUCTION

By using the handle located at the inside or outside of the right arm the footrest can be unfolded and the back can be regulated into rest positions.

The glide/rocker function is locked as long as the footrest is unfolded.



### FOLDED FOOTREST (IN)

- The back is locked in upright position.
- The glide/rocker function can be operated.
- With 360 swing function.
- You can adjust the neck and head support.

### UNFOLDED FOOTREST (OUT)

- The back angle can be adjusted from upright to rest positions
- The glide/rocker function is locked when the footrest is unfolded (out)
- With 360 swing function
- You can adjust the neck and head support

The built-in footrest can be unfolded by pushing the handle placed inside of the right arm - towards the back. To fold in the footrest you should use your feet to press the footrest down towards the chair and move your bodyweight forward in the chair. Note: The handle must be in front position to fold in the footrest. If the chair is equipped with an outside handle please move the handle backward to unfold the built in footrest. To fold in the footrest you should use your feet to press the footrest down in combination with moving the handle forward.

Do not use shoes directly against the footrest. This might cause damage to the cover/upholstery. Do not sit on the armrests. Never lift/carry the chair by the back or the footrest. Lift the chair by grabbing under the chairs arms, base or backside. Two persons are recommended to lift/carry the chair.