







FITTINGS AND PARTS CHECKLIST

BODY	
I Body	
II Arms x 1 pair	
III Ottoman cushion x 1	
IV Screw M6 x 8	
V Hex key x 1	

ASSEMBLING THE BODY ON TO THE BASE


STEP 1

Begin by putting body (I) on the already assembled chair base.




STEP 2

Assemble armrests (II) by inserting screw (IV) half way into the arms. Put the armrests on with screws sticking through the key-holes at the chairs steel arm. Press the arm down and backwards while tightening the screws with hex key (V).



STEP 3

Assembly ottoman by attaching ottoman cushion (III) on the already assembled footstool base by inserting screw M6 (IV) through hole and using hex key (V) to tighten all screws.




CONGRATULATIONS YOUR CHAIR AND OTTOMAN IS READY TO ENJOY.

NB : Please check bolts for tightness every six months or as needed.



CONGRATULATIONS















You are now the proud owner of a Nordic Ring Base. We are confident you will enjoy the comfort and style of this new furniture.



IMPORTANT

Read this and other relevant instructions before using the product. Keep this manual for future reference.

A S S E M B L Y I N S T R U C T I O N S

RING BASE CHAIR	
A Ringbase center x 1	
B Ringbase Chair x 1	
C Plate x 2	
D Screw M8x50 x 5	
E Hex Key x 1	
F Finished Ring Chair Base	
RING BASE OTTOMAN	
G Ottoman up-rights x 1	
H Top Plate Ottoman x 1	
I Ring Base Ottoman x 1	
J Dome screw x 4	
K Stud M6 x 2	
L Screw M6 x 2	
M Hex Key x1	
N Finished Ring Ottoman	

RING BASE ASSEMBLING

STEP 1

Begin by inserting 5 long screw (D) through holes on plate (C) under bottom of ring base (B) as shown in fig. 1.




Fig. 1.

STEP 2

Place the second plate (C) on ring base. Position ringbase center (A) on top of plate shown in fig. 2.




Fig. 2.

STEP 3

Use hex key (E) to tighten each screw securely as shown in fig. 3 to finish the ringbase.




Fig. 3.

STEP 4

Slip one ottoman up-right (G) into slot on ottoman ring (I) and put the second ottoman up-right into other slot. If needed use a rubber hammer to hit softly on top to get the cross in place as shown in fig. 4.





Fig. 4.



STEP 5

Use hex key (M) to tighten screw M6 (L) to lock between ottoman ring (I) and ottoman up-right (G) as shown in fig. 5.




Fig. 5.

STEP 6

Put top plate (H) on top of the ottoman up-rights as shown in fig. 6.






Fig. 6.

STEP 7

Insert stud M6 (K) through top plate and holes on ottoman up-rights and use dome screw (2 pcs.) to tighten and lock top plate with cross ottoman. Fig. 7. shows finished ring ottoman.



LOW



HIGH





Fig. 7.

